

**BAB723/ 2901302/
BAB703/ GBA80250/
2902402/ BAB706/ 2902502**

1	Important safety instructions.....	4	7	Operation.....	5
2	Safety notes and precautions.....	4	7.1	Check battery capacity.....	5
3	Symbols on the product.....	4	8	Technical data.....	6
4	Risk levels.....	4	9	Limited warranty.....	6
5	Proposition 65.....	5			
6	Environmentally safe battery disposal.....	5			

1 IMPORTANT SAFETY INSTRUCTIONS

For the proper use, maintenance and storage of this battery, it is crucially important that you read and understand the instructions given in this manual.

To avoid serious injury, risk of fire, explosion and danger of electric shock or electrocution:

- If the battery pack case is cracked or damaged, DO NOT insert into the charger. Replace with a new battery pack.
- Charge the battery pack only with the recommended charger.
- DO NOT try to short circuit any terminals of battery pack.

▲ WARNING

If the battery fluid gets in your eyes, flush immediately with clean water for at least 15 minutes. Get immediate medical attention. Do not charge the battery pack in rain or in wet conditions. Do not immerse the tool, battery pack, or charger in water or other liquid.

- Do not allow the battery pack or charger to overheat. If they are warm, allow them to cool down. Recharge only at room temperature.
- Do not place the battery pack in the sun or in a warm environment. Keep at normal room temperature.
- Store in shady, cool and dry environments. If battery has not been charged for an extended period of time, charge for at least two (2) hours every two (2) months.
- The battery pack cells may develop a small leak under extreme usage or temperature conditions. If the outer seal is broken and the leakage gets on your skin:
 - Use soap and water to wash immediately.
 - Neutralize with lemon juice, vinegar, or other mild liquid.

- If leakage gets in your eyes, follow instructions above and seek medical attention.
- Please check prior use, if output voltage and current of the battery charger is suitable for the battery pack.
- Use protective packaging when transporting battery pack.
- Handle with care.
- Keep away from humidity and fire.



2 SAFETY NOTES AND PRECAUTIONS

- Do not disassemble the battery.
- Keep away from the children.
- Do not expose battery to water or salt.
- Battery should be stored in cool, dry location.
- Do not place the battery in high-temperature locations, such as near a fire, heater, etc.
- Do not reverse the positive terminal and the negative terminal of the battery.

- Do not connect the positive terminal and the negative terminal of the battery to each other with any metal objects.
- Do not knock, strike or step on the battery.
- Do not solder directly onto the battery or pierce the battery with nails or other sharp tools.
- In the event that the battery leaks and the fluid gets into one's eye, do not rub the eye. Rinse thoroughly with water.
- Immediately discontinue use of the battery, if, while using, the battery emits an unusual smell, feels hot, changes color, changes shape, or appears abnormal in any other way.




3 SYMBOLS ON THE PRODUCT

Some of the following symbols may be used on this tool. Please study them and learn their meaning. Proper interpretation of these symbols will allow you to operate the tool better and safer.

Symbol	Explanation
V	Voltage
W	Power
≡	Direct current
	Read all safety warnings and all instructions.
	Precautions that involve your safety.

4 RISK LEVELS

The following signal words and meanings are intended to explain the levels of risk associated with this product.

SYM-BOL	SIGNAL	MEANING
	DANGER	Indicates an imminently hazardous situation, which, if not avoided, will result in death or serious injury.
	WARNING	Indicates a potentially hazardous situation, which, if not avoided, could result in death or serious injury.
	CAUTION	Indicates a potentially hazardous situation, which, if not avoided, may result in minor or moderate injury.
	CAUTION	(Without Safety Alert Symbol) Indicates a situation that may result in property damage.

5 PROPOSITION 65

▲ WARNING

This product contains a chemical known to the state of California to cause cancer, birth defects or other reproductive harm. Some dust created by power sanding, sawing, grinding, drilling, and other construction activities contains chemicals known to cause cancer, birth defects or other reproductive harm. Some examples of these chemicals are:

- Lead from lead-based paints;
- Crystalline silica from bricks and cement and other masonry products;
- Arsenic and chromium from chemically treated lumber.

Your risk of exposure to these chemicals varies depending on how often you do this type of work. To reduce your exposure to these chemicals, work in a well-ventilated area, and work with approved safety equipment, such as dust masks that are specially designed to filter out microscopic particles.

6 ENVIRONMENTALLY SAFE BATTERY DISPOSAL



▲ WARNING


If the battery pack cracks or breaks, with or without leaks, do not recharge it and do not use. Dispose of the battery and replace with a new battery pack. **DO NOT ATTEMPT TO REPAIR IT!** To avoid injury and risk of fire, explosion, or electric shock, and to avoid damage to the environment:

- Cover the battery's terminals with heavy-duty adhesive tape.
- DO NOT attempt to remove or destroy any of the battery pack components.
- DO NOT attempt to open the battery pack.
- If a leak develops, the released electrolytes are corrosive and toxic. DO NOT get the solution in the eyes or on skin, and do not swallow it.
- DO NOT place these batteries in your regular household trash.
- DO NOT incinerate.
- DO NOT place them where they will become part of any waste landfill or municipal solid waste stream.
- Take them to a certified recycling or disposal center.

7 OPERATION

7.1 CHECK BATTERY CAPACITY

Press the battery capacity indicator (BCI) button. The lights will illuminate according to the batteries capacity level. See chart below:



Lights	Capacity
3 Green Lights	The battery is more than 75% capacity.
2 Green Lights	The battery is between 35% and 75% capacity.
1 Green Light	The battery is less than 35% capacity.
Lights go out	The battery requires charging immediately.



Lights	Capacity
4 Green Lights	The battery is above 80% capacity
3 Green Lights	The battery is between 80% and 60% capacity.
2 Green Lights	The battery is between 60% and 40% capacity.
1 Green Light	The battery is between 40% and 20% capacity.
1 Blinking Green Light	The battery is between 20% and 10% capacity.
Lights go out	The battery is less than 10% capacity and requires charging immediately.

- * 1. BATTERY CAPACITY INDICATOR (BCI) BUTTON
- 2. LED CAPACITY INDICATOR

BATTERY PROTECTION FEATURES

This lithium-ion battery packs are designed with features that protect the lithium-ion cells and maximize battery life.

If the tool stops during use, release the trigger to reset and resume operation. If the tool still does not work, the battery needs to be recharged.

COLD WEATHER OPERATION

The lithium-ion battery pack can be used in temperatures down to -14°C (6.8°F). Put the battery pack on a tool and use the tool in a light duty application. After about a minute, the pack will warm up and begin operating normally.

8 TECHNICAL DATA

Model	2901302
Battery	72 V \square , 2Ah, 144Wh, 80V Max
Charge time	60min. (use GCH8020/ CAB801 Charger)
	30min. (use 2901402 Charger)
	24min. (1 Battery)/ 30min. (2 Batteries) (use CAB812 Charger)

Model	GBA80250
Battery	72 V \square , 2.5Ah, 180Wh, 80V Max
Charge time	75min. (use GCH8020/ CAB801 Charger)
	38min. (use 2901402 Charger)
	30min. (1 Battery)/ 40min. (2 Batteries) (use CAB812 Charger)

Model	BAB703
Battery	72 V \square , 3Ah, 216Wh, 80V Max
Charge time	90min. (use GCH8020/ CAB801 Charger)
	45min. (use 2901402 Charger)
	min. (1 Battery)/ 45min. (2 Batteries) (use CAB812 Charger)

Model	2981102
Battery	72 V \square , 4Ah, 288Wh, 80V Max
Charge time	120min. (use GCH8020/ CAB801 Charger)
	60min. (use 2901402 Charger)
	20min. (1 Battery)/ 60min. (2 Batteries) (use CAB812 Charger)

Model	BAB723
Battery	72 V \square , 4Ah, 288Wh, 80V Max
Charge time	120min. (use GCH8020/ CAB801 Charger)
	60min. (use 2901402 Charger)
	50min. (1 Battery)/ 60min. (2 Batteries) (use CAB812 Charger)

Model	2902502
Battery	72 V \square , 5Ah, 360Wh, 80V Max

Charge time	150min. (use GCH8020/ CAB801 Charger)
	75min. (use 2901402 Charger)
	40min. (1 Battery)/ 75min. (2 Batteries) (use CAB812 Charger)

Model	BAB706
Battery	72 V \square , 6Ah, 432Wh, 80V Max
Charge time	180min. (use GCH8020/ CAB801 Charger)
	90min. (use 2901402 Charger)
	45min. (1 Battery)/ 90min. (2 Batteries) (use CAB812 Charger)

9 LIMITED WARRANTY

90-Day Warranty

Renewed/Refurbished products and batteries are protected against all defects in materials, parts or workmanship under normal use for a period of 90 days from the shipping date or in-store purchase date.

ITEMS NOT COVERED BY WARRANTY:

1. Any part that has become inoperative due to misuse, commercial use, abuse, neglect, accident, improper maintenance, or alteration; or
2. The unit, if it has not been operated and/or maintained in accordance with the owner's manual; or
3. Normal wear;
4. Routine maintenance items such as lubricants, blade sharpening;
5. Normal deterioration of the exterior finish due to use or exposure.

HELPLINE:

Warranty service is available by calling our toll-free helpline, at 1-855-345-3934.

TRANSPORTATION CHARGES:

Transportation charges for the movement of any power equipment unit or attachment are the responsibility of the purchaser. It is the purchaser's responsibility to pay transportation charges for any part submitted for replacement under this warranty unless such return is requested in writing by Greenworks.

USA address:

Greenworks Tools
P.O. Box 1238
Mooresville, NC 28115

Canadian address:

Greenworks Tools Canada Inc.
P.O. Box 93095, Newmarket,
Ontario
L3Y 8K3

www.greenworkstools.com



greenworks pro

P0801915-03 Rev B